



Cawlin' Crow^{v13.1}
#69209-7

Thank you for purchasing a Lucky Duck Premium Decoy. To view additional Lucky Duck™ products please visit your local Sporting Goods dealer or www.luckyduck.com.

Instructions for use:

- 1) Remove the battery cover from the bottom of the unit and install 4-AA batteries. Negative battery terminals always contact the spring. Replace the battery cover.
- 2) NOTE: **DO NOT MIX OLD & NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD (carbon zinc) OR RECHARGEABLE (ni-cad, ni-mh, etc) BATTERIES.**
- 3) Remove/pull the stake out of the body and press the pointed end into the ground. Then mount the crow decoy onto the stake at the hole in the chest.
- 4) To start the crow Cawlin', press the switch to the I position. The decoy will immediately start Cawlin'. If you do not want your decoy to start Cawlin' right away so you have time to set up, go to step 5.
- 5) There is a delay start option built into this decoy. This allows you to have time to get set up before it starts Cawlin'. Simply press the switch button to the II position. The unit will then turn on in a 1.5 minute sleep mode before it starts Cawlin'.

Lucky Duck™ warrants this product against all manufacturing defects for a period of 1 year from date of purchase. Proof of purchase is required. Abuse of the product (submerged in water, dropped, mistreatment etc.) is not covered. Please return and exchange the defective unit to the store where you purchased the product. If the store will not accept the return, please call customer service at 715-338-3183.



Lucky Duck™

A Division of Expedite International Inc.
1201 Beaudry Blvd
Hudson WI 54016
www.luckyduck.com

