



**FAWN DECOY v13.1**  
**#51208-1**

Thank you for purchasing a Lucky Duck™ Premium Decoy.

To view additional hunting products please visit your local sporting goods dealer or logon to [www.luckyduck.com](http://www.luckyduck.com).

**Your package should include:**

- ❖ Rubber Fawn Decoy
- ❖ (1) top & (1) bottom mounting stake
- ❖ (1) black screw
- ❖ (2) nuts
- ❖ (1) tail

- 1) Unroll rubber fawn decoy.

*TIP: You are going to want to let it sit outside for a day or so to air out. It will have a paint smell when first opened, but will disappear quickly once left out. If you are concerned, you may wash it in scent free soap bath to speed up the airing out process.*

- 2) Attach the tail mounting hardware to the decoy at the back where the tail would be attached. You will have 1 black screw and 2 nuts. Remove 1 nut from the assembly and insert the screw with 1 nut still threaded on through the hole in the back of the decoy. Thread on the removed nut and secure by hand tightening. You may use a pliers or wrench to finish tightening. **DO NOT OVER TIGHTEN.** A half turn after hand tightening should be plenty.
- 3) Attach the tail to the fawn body by sliding the keyway on the back of the tail over the protruding screw from the back of the decoy.
- 4) Press point section of (2) piece mounting stake into the ground
- 5) Attach the top section to the bottom section by aligning the boss on the base of the top stake section with the slot on the bottom stake section and sliding the top section down over the bottom section and making a quarter turn to secure the two sections together.
- 6) Put the assembled stake inside the decoy, line up the top of stake (plastic protrusion) with the hole in the top of the decoy and push it thru the hole. (It will be tight)
- 7) This completes the setup-We hope it brings you success in the field!

**Troubleshooting:**

If you have problems with your decoy not returning to it's original shape when unrolling it for the first time you can submerge it in hot water and it will return to it's original shape. You can also just set it out in the hot sun for a few hours and this will also work. **CAUTION: DO NOT OVERHEAT, AS THE MATERIAL IS TEMPERATURE SENSITIVE AND MAY DEFORM IF EXTREME HEAT IS APPLIED.**

**Warranty: Lucky Duck™ warrants this product against all manufacturing defects for a period of 1 year from date of purchase. Proof of purchase is required. Abuse of the product (submerged in water, dropped, mistreatment etc.) is not covered. Please return and exchange the defective unit to the store where you purchased the product. If the store will not accept the return, please call our customer service phone number at 715-338-3183.**

**Lucky Duck™**

A Division of Expedite International Inc.  
1950 8<sup>th</sup> Ave, Baldwin WI 54002  
[www.luckyduck.com](http://www.luckyduck.com)