

## Lucky HD Collapsible Hen #50117-7, Lucky HD Collapsible Jake #50217-4

Thank you for purchasing the Lucky HD collapsible turkey decoy(s). To see more Lucky Duck™ products please visit your local Sporting Goods dealer or online at <a href="https://www.luckyduck.com">www.luckyduck.com</a>.

The Lucky HD turkey decoys are extremely realistic and the most versatile turkey decoy on the market. These decoys are lightweight, can be collapsed to save space, and make transportation to and from your hunting spot much easier.

Step 1: To expand the decoy unplug the valve and blow air into the valve. Plug the valve hole to maintain the shape of the decoy. If the decoy does not fully expand after long periods of storage, set the decoy in the sun for a few hours or run warm water over the decoy.

**Step 2:** Connect the two-piece stake.

**Step 3:** Using the footstep, insert the stake into the ground. The footstep is located on the bottom section of the stake. When removing the stake from the ground, pull up on the bottom section of the stake closest to the ground.

Step 4: Set the decoy on the stake and secure the decoy bungee to the hook on the stake.

**Note:** To collapse the decoy, unplug the valve and push on the bottom of the decoy. Once collapsed, plug the valve to maintain the collapsed shape.

Lucky Duck™ warrants this product against all manufacturing defects for a period of 1 year from date of purchase. Proof of purchase is required. Abuse of the product (submerged in water, dropped, mistreatment etc.) is not covered. Please return and exchange the defective unit to the store where you purchased the product. If the store will not accept the return, please call or email customer service at 715-338-3183 or customerservice@luckyduck.com.

Lucky Duck™

A Division of Expedite International Inc.

1950 8<sup>th</sup> Ave

Baldwin, WI 54002

Customer Service 715-338-3183, customerservice@luckyduck.com

www.luckyduck.com