



## Quiver Duck Butt HD™ #10517-7

Thank you for purchasing the Quiver Duck Butt HD. To see more Lucky Duck™ products please visit your local Sporting Goods dealer or online at [www.luckyduck.com](http://www.luckyduck.com).

**Step 1:** Carefully remove Quiver Duck Butt HD from its packaging.

**Step 2:** Unscrew the module from the bottom of the decoy.

**Step 3:** Insert 4 "AA" batteries and secure in place by pivoting the locking battery tabs over the batteries.

**DO NOT MIX OLD & NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD (CARBON ZINC) OR RECHARGEABLE (ni-cad, ni-mh, etc) BATTERIES.**

**Step 4:** Replace the module and ensure the module is secured tightly for a waterproof seal.

**Step 5:** Attach the anchor and cord to the loop on the bottom of the decoy module.

**Step 6:** The decoy has a water activation switch that turns the decoy on when set in the water and turns the decoy off when removed from the water. When the two silver contacts on the bottom of the module are both submerged under water the decoy turns on. If the decoy continues to remain on when removed from the water simply wipe the two silver contacts with your hand or clothing. The decoy will turn off.

**Step 7:** Place the Quiver Duck Butt HD directly in the water among your decoy spread and watch your decoy(s) come alive.

**Tip:** To test the decoy out of the water simply assemble your decoy as described above and set the silver contacts on a wet towel or in a small water bowl. Pure filtered water may not be conductive enough to turn the decoy on.

### Storage:

After each hunt check the battery module to see if moisture is present inside the module. If moisture is present leave the module unattached from the decoy until it is dry. Remove the batteries from the module while in storage.

**The decoy's electrical components have a slow drain if the battery is connected even when the decoy is not running.**

**Lucky Duck™ warrants this product against all manufacturing defects for a period of 1 year from date of purchase. Proof of purchase is required. Abuse of the product (submerged in water, dropped, mistreatment etc.) is not covered. Please return and exchange the defective unit to the store where you purchased the product. If the store will not accept the return, please call customer service at 715-338-3183.**

**Lucky Duck™**  
A Division of Expedite International Inc.  
1950 8<sup>th</sup> Ave  
Baldwin, WI 54002  
Customer Service 715-338-3183  
[www.luckyduck.com](http://www.luckyduck.com)

